


ZD10 Installation Manual

Contents


1. Check ZD10 Parts
2. Check Installation environment
3. Check Board Installation
4. Check Cable Connection
5. Check Air Hose
6. Check ZD10 Needle Bar
 - 1) Check Needle Upper / Drop Point
7. Check ZD10 DEVICE Installation
 - 1) Check Needle Position
 - 2) Check ZD Motor Synchronization
8. Embroidery TEST.

1 Check ZD10 Parts.


1) ZD10 Device



2) Boards






3) Cables




4) Air Hose







5) ZD10 Needle & Needle Bar



ZD10 Needle Length

- ① SB,DM,CE,K,E-Series
200.1mm
(GP-034102-33)
- ② D,TA,CA,SA-Series
195.1mm
(GP-034407-03)

6) Jig



2 Check Installation environment

(1) Option Specification

- 1) The type of Control B/D depends on whether SQ40I is intalled or not.
 - SQ40I is not installed : Used Control B/D only for ZD10
 - SQ40I & ZD10 installed : Used control B/D for both SQ40I & ZD10.



(2) SMPS Specification for quantity (DC-800-2009-00000282)

1) SMPS quantity depends on option type.

1. Control Box UI 24V SMPS(PBA600F-24)


Option Device	Multi E, K - Series				Multi SB - Series			Multi DM - Series		
	15 ↓	16 ~ 26	27 ~ 29	30 ↑	26 ↓	27 ~ 29	30 ↑	30 ↓	30 ~ 40	
Without Option	1	2	2	3	2	2	3	2	3	
Single Type SQ30 or SQ300	1	2	2	3	2	2	3	3	3	
Both Type SQ30 or SQ300	1	2	2	3	2	2	3	3	3	
Single Type ZD10	1	2	2	3	2	2	3	3	3	
Single or Both Type SQ40i	2	2	2	3	2	2	3	3	3	
SQ30 or SQ300 + ZD10	2	2	2	3	2	2	3	3	3	
SQ40i + ZD10	2	2	3	3	2	3	3	3	3	

3 Check Board Installation


(1) Control B/D and Sub Control Board for ZD10

※ Modification(2008.1.22) : Sequin Lifting B/D needs only for ZD10 installation.

Modification (2008.2.28) : Control B/D includes function of Sequing Lifting B/D, so don't need Sequin Lifting B/D only for ZD installation.



Control B/D 1EA/M
(Matter, ZD10 Lifting Up when Sudden Power Cut modified)



Sub Control B/D(THSB REV05A SB_ZZ) 1EA/H
(Head on/off Function)

※ Input Jumper Pin in Last head.
(normal Head doesn't need)


4 Check Cable Connection

※ Modification(2008.1.22) : Sequin Lifting B/D needs only for ZD10 installation.

Modification (2008.2.28) : Control B/D includes function of Sequin Lifting B/D,
so don't need Sequin Lifting B/D only for ZD installation.


※ Cable Connection depends on option type and need careness.

(1) Calbe Connection Diagram




(2) Cable Connection


1) Check Power Cable Connection




2) Check Encoder Joint Cable and Joint Connection




3) CAN1 & CAN2 Communication Cable Connection




4) Check ZD10 Device Cable Connection



5) Check Sol. Power Cable Connection






※ Sol. type (1P,2P,3P,4P) and quantity depend on option type and alternative fuction, when installing, care about it.

※ Sol. type and Cable Quantity

	Sol.	Cable	
SINGLE-Type	1	2	
SINGLE-Type	2	4	alternative
BOTH-Type	2	4	
BOTH-Type	4	8	alternative

	Conection		Cable
LIFT SOL#1	RIGHT LIFT(ODD)_DN	A	1
	RIGHT LIFT(ODD)_UP	B	1
LIFT SOL#2	RIGHT LIFT(EVEN)_DN	A	1
	RIGHT LIFT(EVEN)_UP	B	1

6) Check Air Error Check Cable




5 Check Air Connection

(1) Check 8mm Hose



(2) Check Nipple (KQ2T06-04, 2EA) in each head.

- 1) Quantity of Nipple is two for each device.
- 2) Quantity of Nipple depends on Option type.




(3) Check Nipple (KQ2T06-00, 2EA) in the middle of Beam (KQ2T06-00).


- 1) Nipple(KQ2T06-00, 2EA) functions to supply air to Nipple (KQ2T06-04) from Air Sol.

Nipple(KQ2T06-00) : 2EA / Option

※ Quantity of Nipple(KQ2T06-00) depends on option type and alternative function.




(4) Check whether Nipple(KQ2T06-04) blocks with Plug in First and Last Head.



(5) Chck Hose Connection


- 1) Check Hose(6mm, Transparent & Black) in Nipple (KQ2T06-00) from Sol.
- 2) Check Hose between Nipple (KQ2T06-04) all heads.

Check Hose (6mm, Transparent & Black) between Nipple (KQ2T06-00) and Nipple (KQ2T06-04) in the middle of beam.



※ Hose Connection depends on option type and alternatvie function.

- 3) Check the hose (4mm, Transparent & Black) to Nipple (KQ2T06-04) from Device.




6 Check ZD Needle Bar

- (1) ZD use exclusive ZD needle Bar.

1) The procedure to exchange needle bar is the same as normal needle bar.

※ But, ZD doesn't use Presser Foot, so don't need related parts (Presser Foot Holder etc.).






2) Check the Needle drop Point in Main Angle 201 degree.

※ Use Normal Jig (17.7mm) and ZD Jig (11.8mm) together like picture.

※ ZD Jig (5mm) is for old type of ZD which is not available for ZD Height.

– Old type of ZD use different needle bar & needle from current one.






1. Old Type (~2008.02.01)
2. Old Type Needle Bar (Needle BQ#14)

3) Check Upper Dead Point in 0 degree.

7 Check ZD10 Device




(1) Check the Gap between Nipple and needle Plate as 3mm.

※ If it is wrong, set it again.





(2) Check Needle Bar Position and if it is wrong, set it again.


※ Refer to ZD Manual for details.




(3) Check Nipple direction whether it matches to cord thread supply hole.
If it is wrong, set it again.



- 1) Select Zigzag Motor Set in "Machine -> Machine Service".
- 2) if push start "Zigzag Motor Set", Motor become off.
- 3) In the condition of Motor Off, Loosen the Pulley screws so that Pulley can not be effected by Motor.
- Use 2.5mm wrench for screws.



- 4) After loosening screws, Push "Stop" button to power Motor on and then make nipple hole to the direction of cord thread and fix the screws.
- L type 3 O'clock direction, R type 9 O'clock direction



8 Embroidery Test

※ Run embroidery test using the fabric and thread provided by a client and test design.

Check the machine status.

※ Run a test using the design provided by a client.

Write productivity result report. Attach original design and the work sample to the report.

※When running an embroidery test, train the staff and administrator from a client company on machine control and maintenance.

※Refer to, and follow directions in, installation manual and installation check list.

I. ZD10 Check List

Country		M/C Type	
Agent		Serial No.	
Customer		Version Date	
Installation Date		Installation Technician	

Order	Items to be Checked
1	Check ZD10 Parts
	1. ZD10 Device () 2. Boards () 3. Cable () 4. Air Parts () 5. ZD10 Needle & Needle bar () 6. Jig ()
2	Check machine installation and exterior conditions
	(1) SMPS Quantity - Check proper quantity of SMPS. ()
3	Check Boards
	(1) Check Control Board - Check whether it is available for option type. () (2) Check Jumper in last sub control board ()
4	Check Cable & Air Parts
	(1) Check Power Cable Condition. () (2) Check Encoder Junction cable and Joint board connection. () (3) Check CAN1 & CAN2 and CAN Junction connection. (4) Check ZD10 Device Motor Cable. () (5) Check Sol. Power Cable Connection. () (6) Check Air Error Check Cable Connection. () (7) Check Hose connection, 8mm, 6mm (Transparent,Black), 4mm(Transparent,Black). () (8) Check the Pulg in first & last Head. ()

5	Check ZD10 needle bar (Pass : O, Fail : X)																																																																																																																																																																								
	<p>(1) Check Needle Bar Upper / Lower dead point.</p> <p>① Needle bar Upper & Lower dead point</p> <table border="1"> <tr> <td>Head</td> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td> </tr> <tr> <td>Condition</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table> <p>② ZD10 Nipple Height Setting (3mm).</p> <table border="1"> <tr> <td>Head</td> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td> </tr> <tr> <td>Condition</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table> <p>③ ZD10 Needle Bar position.</p> <table border="1"> <tr> <td>Head</td> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td> </tr> <tr> <td>Condition</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table> <p>④ ZD10 Motor synchronization</p> <table border="1"> <tr> <td>Head</td> <td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td> </tr> <tr> <td>Condition</td> <td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td> </tr> </table>	Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	Condition																					Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	Condition																					Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	Condition																					Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	Condition																				
Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20																																																																																																																																																					
Condition																																																																																																																																																																									
Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20																																																																																																																																																					
Condition																																																																																																																																																																									
Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20																																																																																																																																																					
Condition																																																																																																																																																																									
Head	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20																																																																																																																																																					
Condition																																																																																																																																																																									
6	Embroidery TEST.																																																																																																																																																																								
	<p>※ Run embroidery test using the fabric and thread provided by a client and test design. Check the machine status.</p> <p>※ Run a test using the design provided by a client. Write productivity result report. Attach original design and the work sample to the report.</p> <p>※ When running an embroidery test, train the staff and administrator from a client company on machine control and maintenance.</p>																																																																																																																																																																								